

ASSEMBLING INSTRUCTION**WINKER SPACER FITTING****TT9112-16****WWW.BARRACUDAMOTO.COM****LEGEND**

1. SCREW M6X35
VITE M6X335
TORNILLO M6X35
SCHRAUBE M6X35
VIS M6X35
2. SPECIFIC THICKNESS H6MM
SPESSORE SPECIFICO H6MM
ESPACIADOR H6MM
ABSTANDSHALTER H6MM
ESPACEUR H6MM

